

P06

QUICK INSTALL


快速安装



北京炜煌科技发展有限公司
Beijing Bright Technology Development Co., Ltd



● 打印机各部件一览 Printer Parts Names



1. SET 设置 SET Button

2. LF 键 LF Button

3. 纸仓盖 Paper Case Cover

4. 锁 Lock

5. 钥匙 Key

6. 天线 Aerial

7. 壁挂 Wall-mounted parts

8. 备用接 Reserve Connector

9. 电源接口 Power Connector

10. 电源开关 Power Switch

按钮开关的操作及指示灯

打印机上电后指示灯保持常亮状态，打印机缺纸时指示灯闪，不能接受数据。

正常上电后，LF 键为走纸键，SET 键为查询黑标位置。

自检测方式

打印机断电，按 LF 键不放手同时给打印机上电，打印机就会打印出自检条。

Operation Specification


After turning on the printer, the indicator light will keep on. When the light flash, it shows that the paper is lacking, and the printer can not receive data.

Press the LF button, the printer will feed paper.

The Self Test

Press the LF button, do not release and turn on the printer at the same time, and then the printer will print out the self-check scrip.


● 尺寸 Size



WH-P06 型尺寸 Product Size:

外型尺寸 Outline Dimension: 137mm X168.8 mm X 225.9mm

● 安装 Installation



安装方法:

P06 打印机安装方式有两种:


- 1、可直接放置在水平桌面上使用。
- 2、壁挂使用，把配带的壁挂支架固定墙壁上，然后将打印机后背对准壁挂支架，由上向下挂在壁挂支架上。注意需把打印机挂到位，防止打印机晃动掉落。

Installation Method:

Method 1: Use on the table.

Method 2: Fix the wall-mounted parts on the wall, then hang the printer on the wall-mounted parts in place.

● 连接 Connection



通讯连接:

请严格参照产品背面标签所注参数进行连接。

电源连接:

请严格参照产品背面标签所注参数进行连接。

注意：不要将交流 220V 与打印机电源插座直接连接，工作电压应在额定电压 $\pm 5\%$ 以内，电源极性一定要接正确，否则会给打印机造成永久性损坏，炜煌公司对此不承担保修义务。

Communication Connection:


Please refer to the label of printer.

Power Connection:

Please refer to the label of printer.

Attention: Do not connect AC to the printer directly, operating voltage should be within $\pm 5\%$ rated voltage. Power polarity must be correct, otherwise it will cause permanent damage to printer, brightek company do not assume maintenance compulsory upon this.

●装纸 Paper Roll




安装步骤:

1. 如图 1 所示, 按箭头位置将钥匙插入壳体侧面锁中, 顺时针方向旋转钥匙打开纸仓门, 见图 2。
2. 将打印纸套在纸轴上, 拆掉打印纸封口标签装入纸仓, 并拉出一截(超出一点撕纸牙齿), 注意把纸放整齐, 纸的方向为有药液一面(光滑面)向上, 如图 3。
3. 合上纸仓盖, 打印头走纸轴压齐打印纸后稍用力把打印头走纸轴压回打印头。
4. 接通打印机的电源, 使机头转动, 这时看一下纸是否走歪, 待机或关上电源。

Replacing the Paper Roll

1. Turn the key in the lock as shown in Fig 1, and open the paper cover.
2. Insert the paper into the printer, Pull out a small amount of paper. Notice the direction of the paper according to Fig.3.
3. Close the paper cover. Press the platen roller back to the printer head.
4. Power the printer on, then press LF button, make the print head to run, and the paper will come out. Turn off the power.

● 清洁 Cleaning



清洁保养：

热敏打印机使用久了以后，热敏条与滚轴上会留下一些污垢，如果不及时清理会影响到打印机的使用与寿命。我们建议您不定期做好清理。方法是打开纸舱盖，用棉棒沾少许酒精，轻轻擦拭打印机热敏头，及纸仓上的滚轴。

Printer Cleaning

If the interior of the printer is dusty, print quality can decline. So please clean the printer regularly. Open the cover of printer, then wipe the printer head with a cleaning pen and use a cloth moistened with an alcohol to solution to clean the paper sensor and the platen roller.

● 产品维护手册

一、打印机故障分析及排除

故障现象	可能原因	处理措施
打印内容空白	打印纸装反	检查打印纸方向是否装反，有药液一面（光滑面）朝向纸仓内
打印内容乱码或不打印接口数据	数据线没插好	检查数据连接线是否有松动或连接是否良好
	串口配置参数不对	串口机型：检查串口配置参数（波特率、数据位、停止位、校验位和流控制）是否与上位机匹配
打印内容颜色比较浅或打印一半	电源电压低	检测打印机供电电源功率是否正常
打印内容缺列或部分内容模糊	机头加热板有异物	关闭打印机电源，打开纸仓盖检查机头加热板上是否有异物或划伤，如有异物，用医用棉签蘸无水酒精清洗；划伤请返回厂家检修
没纸状态下，机头还一直转动	测纸传感器有异物	关闭打印机电源，检查机头测纸传感器表面是否有异物，如有异物，用医用棉签蘸无水酒精清洗

注：打印机内的电子元件不能随意拆卸或更换，如出现故障现象按照以上方法无法修复，请拨打售后技术支持电话：400-666-6868

二、打印机使用注意事项和日常保养

- 1、使用打印机之前，先将各种线完全插好，检查连接正常后再开机。**注意：串口机型不能带电插拔数据线。**
- 2、必须使用原厂配备电源和连接线，否则打印机将出现异常现象。
- 3、必须使用符合要求的纸卷。（如纸厚度、宽度、打印面比较光滑等），以延长打印机加热板寿命。
- 4、打印机不得在无纸的状态下（没有缺纸报警）打印，否则将严重损害热敏打印头。
- 5、避免水或导电的物质（例如：金属）进入打印机内部，一旦发生，应立即关闭电源。
- 6、打印机在暂时不用时应将电源关闭，以延长打印机使用寿命。
- 7、定期清理打印机加热板和滚轴表面，以免影响打印内容的效果。
- 8、定期清理机头测纸传感器表面的异物，防止出现缺纸不报或误报警现象。
- 9、打印机在出现异常故障现象时，请先切断电源，然后通知相关人员进行检修。

注：在日常保养时，必须确保关闭电源，不要用手或金属物体触摸机头加热板和胶辊的表面。